



FTI AIR AODD MODELS FT30A & FT30S

Assembly, Installation, & Operation Manual

P/N 109692 R7



Record your Model and Serial Number here.

MODEL NUMBER _____

SERIAL NUMBER _____



A DIVISION OF FINISH THOMPSON INC.
921 Greengarden Rd • Erie, PA 16501 USA
Ph: 814-455-4478 • Fax: 814-455-8518
www.ftiair.com

EU Declaration of Conformity



FTI Air hereby declares that the following machine(s) fully comply with the applicable health and safety requirements as specified by the EC Directives listed. The complete product complies with the provisions of the EC Directive on machinery safety.

This declaration is valid provided that the devices are fully assembled and no modifications are made to these devices.

Type of Device:

Air Operated Double Diaphragm Pumps

Models:

FT025P, FT025V, FT025C, FT05P, FT05V, FT05A, FT05S,
FT10P, FT10V, FT10A, FT10S, FT15P, FT15V, FT15A, FT15S, FT15ZP, FT15ZV, FT15ZA, FT15ZS,
FT20P, FT20V, FT20A, FT20S, FT30A & FT30S

EC Directives:

Machinery Safety (2006/42/EC)

Applied Harmonized Standards:

EN ISO 12100

Manufacturer:

FTI Air A Division of Finish Thompson, Inc.
921 Greengarden Road
Erie, Pennsylvania 16501-1591 U.S.A

Signed,

President


23 May 2019

Person(s) Authorized to Compile Technical File: FTI Air GmbH
Otto-Hahn-Strasse 16
Maintal, D-63477 DEU
Telephone: 49 (0)6181-90878-0

EU Declaration of Conformity

Manufactured by:

Finish Thompson, Inc.
921 Greengarden Road
Erie, Pennsylvania 16501 U.S.A.
Phone: 1-(814)-455-4478
Fax 1-(814)-455-8518
Email: fti@finishthompson.com
Web: www.finishthompson.com



This declaration applies to **FTI Air ATEX Series** AODD pumps, being designated by the letter -A- in the model number, and only manufactured out of metallic or carbon fiber filled PP designated by the model numbers FTXX[Z]A, FTXX[Z]S, or FTXX[Z]C, with metallic or carbon fiber filled non-wetted parts designated by the letters -AA- or -CD- within the model number. Pumps and their model numbers may also contain different combinations of diaphragms, balls, seats, o-rings, port connections, and other options.

Example Model Numbers: FT05C-CD-2TPC-B1-A, FT05A-AA-NNAN-B1-A, FT15ZA-AA-BBAB-B2-A

Finish Thompson declares under our sole responsibility that the product listed below conforms to the relevant provisions of EU directive 2014/34/EU of 26 February 2014 for equipment and protective systems intended for use in potentially explosive atmospheres, and is certified for safe use in Group II category 2 areas.

This product has used the following harmonized standards to verify conformance:

Non-electrical equipment for potentially explosive atmospheres: EN ISO 80079-36:2016
Basic Methods and Requirements.

Non-electrical equipment intended for use in potentially explosive atmospheres: EN ISO 80079-37:2016
Protection by construction safety "ch" and control of ignition source "bh".

This product must not be used in areas other than specified above. If in doubt consult an authorized distributor, or refer to the manufacturer Finish Thompson.

Approved by:

Date: 05/23/2019

Table of Contents

Important Information - READ ME FIRST

Export Regulation Notice	5
Chemical Reaction Disclaimer	5
Safety Precautions	5-7

Pump Specifications

Technical Specifications.....	7
Materials Profiles	8
FT30S Dimensional Drawing.....	9
Model Number Explanation & Example Part Numbers.....	9
FT30A Dimensional Drawing.....	10
Performance Curve.....	10

Installation/Operation

Installation Drawing.....	11
Precautions.....	11-12
Troubleshooting.....	12

Maintenance

Recommended Tools	13
Wet End Servicing	13
Disassembly	13-14
Reassembly	15-18
Air End Servicing	19
Shaft Bushing & O-ring Replacement.....	19-20
Air Valve O-ring Replacement.....	21
Valve & Muffler Gasket Replacement.....	22-23
Air Valve Slide, Plate, & Gasket Orientation.....	22
Replacement Air Valve Kit Installation.....	24
Exploded View	24
Spare Parts List.....	24-28

Warranty	29
----------------	----

Important Information- Read Me first

IMPORTANT NOTICE

U.S. Export Administration Regulations, pursuant to ECCN 2B350, prohibit the export or re-export to certain enumerated countries of air operated double diaphragm pumps in which all wetted materials are constructed from fluoropolymers without first applying for and obtaining a license from the U.S. Bureau of Industry and Security(BIS). This affects all FTI AIR pumps constructed from PVDF with PTFE balls and diaphragms. Please contact the BIS (www.bis.doc.gov) or FTI Air with questions regarding the Regulations or a list of the countries to which they apply.

Chemical Reaction Disclaimer

The user must exercise primary responsibility in selecting the product's materials of construction which are compatible with the fluid(s) that come(s) in contact with the product. The user may consult FTI Air (manufacturer) and a manufacturer's representative/distributor agent to seek a recommendation of the product's material of construction that offers the optimum available chemical compatibility.

However neither manufacturer nor agent shall be liable for product damage or failure, injuries, or any other damage or loss arising out of a reaction, interaction or any chemical effect that occurs between the materials of the product's construction and fluids that come into contact with the product's components.

Unpacking & Inspection

Unpack the pump and examine for any signs of shipping damage. If damage is detected, save the packaging and notify the carrier immediately.

To install the pump, follow the installation instructions provided.

Safety Precautions for ATEX Pumps

⚠ Warning: READ THIS SUPPLEMENTAL INSERT COMPLETELY BEFORE INSTALLING AND OPERATING THIS PUMP. FAILURE TO FOLLOW THESE PRECAUTIONS CAN RESULT IN SERIOUS INJURY OR DEATH.

⚠ WARNING: Static sparking can cause explosion. When operating in a hazardous area or pumping a hazardous fluid, the pump's grounding screw and entire pump system must be grounded to earth to prevent static discharge. This includes but is not limited to pipes, hoses, tanks, containers, valves, etc. Before operating the pump, ensure the electrical continuity throughout the pumping system and earth ground is 1 Ohm or less. If it is greater than 1 Ohm, re- check all grounding connections.

⚠ WARNING: Static sparking can cause explosion. Excessive fluid flow rates and improper tank filling methods can produce static electricity causing an explosion. Ensure safe fluid velocities and tank filling procedures in compliance with EN 13463-1 and CLC/TR 50404.

⚠ WARNING: Risk of explosion. When using FT30 ATEX pumps with Santoprene®, Hytrel®, Polyurethane, or PTFE diaphragms, the following methods must be applied:

- Fluid being pumped must be conductive (soluble in water)
- DO NOT use to self-prime
- DO NOT run the pump dry

⚠ WARNING: Vibrations from operation may cause mounting surfaces and connections to loosen and generate a spark. Ensure the pump and connections are securely mounted and fastened prior to each operation.

⚠ WARNING: Do not exceed minimum and maximum temperature limits of pump components. A table of temperature limits is provided in the "Pump Data" section of the manual.

⚠ WARNING: Prior to operating, check pump for any worn o-rings, gaskets, or seals. Any leaking or damaged o-rings, gaskets, or seals must be repaired or replaced immediately.

⚠ WARNING: Do not exceed maximum pressure stated on the pump serial number sticker.

⚠ WARNING: Pump exhaust may be loud and contain particles. Wear appropriate ear and eye protection. In the event of a diaphragm rupture material can be forced out of the air exhaust muffler. If product is hazardous or toxic, pipe exhaust to appropriate safe area.

⚠ WARNING: Pump must be cleaned on a regular basis to avoid dust buildup greater than 5mm.

⚠ WARNING: The surface temperature of the pump depends upon the temperature of the fluid that is being pumped. The chart below lists different fluid temperatures and the corresponding pump surface temperatures, which determine the Temperature Class when used in a hazardous area.

Fluid Temperature	Maximum Surface Temperature	Temperature Class	Maximum Allowable Surface Temperature
172 F° (78° C)	172° F (78° C)	T6	85° C
203° F (95° C)	203° F (95° C)	T5	100° C
266° F (130° C)	266° F (130 °C)	T4	135° C
383° F (195° C)	383° F (195 °C)	T3	200° C

Safety Precautions

⚠ WARNING: FTI Air maximum temperature limits are based upon the material's mechanical stress only. Maximum temperature is application dependent. Consult a chemical resistance guide or the chemical manufacturer for chemical compatibility and temperature limits.

⚠ WARNING: Chemical Hazard. This pump is used for transferring many types of potentially dangerous chemicals. Always wear protective clothing, eye protection and follow standard safety procedures when handling corrosive or personally harmful materials. Proper procedures should be followed for draining and decontaminating the pump before disassembly and inspection of the pump. There may be small quantities of chemicals present during inspection.

⚠ WARNING: Hot surfaces. FTI Air pumps are capable of handling liquids with temperatures as high as 220°F (104°C). This may cause the outer areas of the pump to become hot as well and could cause burns.

⚠ WARNING: If a diaphragm rupture occurs, material being pumped may be forced out of the air exhaust. Proper care should be taken, always wear protective clothing, eye protection & follow standard safety procedures.

⚠ WARNING: When pumping hazardous liquids, or operating the pump in an enclosed room, it is important to pipe the exhaust air to a safe area.

⚠ WARNING: For polypropylene or PVDF pumps do not exceed 100 psig (6.9 bar) air supply & 120 psig (8.3 bar) for aluminum and stainless steel.

⚠ CAUTION: Before attaching air supply to pump, make sure all airline debris is clear. It is recommended to use a minimum 5μ (micron) air filter before the air valve.

⚠ CAUTION: Do not over-tighten the air inlet fitting or muffler. Too much torque could damage the air valve or muffler plate.

⚠ CAUTION: Before maintenance or repair, close the compressed air line supply valve, bleed the pressure and disconnect air line from the pump. Discharge line may also be pressurized. Any pressure must be relieved prior to servicing. Isolate and remove suction / discharge lines & drain the pump. Note that flooded suction systems could be subject to significant leaking through the exhaust before suction isolation valve is closed.

⚠ CAUTION: If pump is used with materials that tend to solidify or settle, the pump should be flushed after each use to prevent damage.

⚠ CAUTION: Use only genuine FTI Air replacement parts to assure compatibility & longest service life.

⚠ CAUTION: Check the temperature limits for all wetted components when choosing pump materials. See Materials Profiles table on page 7.

⚠ EXPLOSION HAZARD! FTI Air pumps with standard materials of construction should not be used with halogenated hydrocarbons. Halogenated hydrocarbon solvents can cause explosion when used with aluminum components in a closed (pressurized) system. FTI Air pumps with standard materials of construction contain aluminum components and will be affected by halogenated hydrocarbon solvents.

1-1-1 Trichloroethane and Methylene Chloride are the most common halogenated hydrocarbons. However, other halogenated hydrocarbon solvents are suspect if used either as part of paint or adhesive formulation, or for clean-up flushing.

For applications that may involve halogenated hydrocarbons, contact FTI Air to discuss the availability of alternative pump materials of construction.

Technical Specifications

Pump Type: Metallic Air Operated Double Diaphragm	
Weight: Aluminum - 155 lbs (70.3 kg) 316SS - 235 lbs (107 kg)	Max Suction Lift: Wet - 29 ft H ₂ O (8.8 m H ₂ O) Dry - Rubber: 18.5 ft H ₂ O (5.6 m H ₂ O) TPE: 12 ft H ₂ O (3.7 m H ₂ O) PTFE: 14 ft H ₂ O (4.3 m H ₂ O)
Air Inlet/Exhaust Size: 3/4" FNPT	Max Flow Rate: 240 gpm (908 lpm)
Max Air Inlet Pressure: 120 psig (8.3 bar)	Suction/Discharge Size: 3" FNPT/FBSP
Max Material Inlet Pressure: 10 psig (0.7 bar)	Max Particle Size: 0.50" (12.7 mm)
Air Consumption @ 100 psi: 150 scfm (255 Nm ³ /hr)	Max Outlet Pressure: 120 psig (8.3 bar)
Noise Level: 86.5 dB(A)	Displacement Per Stroke: 0.98 gal (3.7 liter)


Material Profiles

Material	Chemical Composition	Description	Operating Temperature	
			Minimum	Maximum
Polypropylene	Pure Polypropylene	Thermoplastic that is resistant to alkali and strong acids.	32°F (0°C)	158°F (70°C)
PVDF	Pure Polyvinylidene Fluoride	Strong fluoropolymer with excellent chemical resistance.	10°F (-12°C)	220°F (104°C)
Stainless Steel	316 Stainless Steel	Excellent chemical resistance, high tensile and impact strength, abrasion resistant.	Limited by other materials used	
Aluminum	ADC 12, LM24, LM25	Moderate chemical resistance with good impact strength and abrasion resistance.	Limited by other materials used	
Buna	Acrylonitrile-butadiene Rubber	General purpose elastomer. Resistant to oil, water, solvent, and hydraulic fluid.	10°F (-12°C)	190°F (88°C)
EPDM	Ethylene Propylene Diene Rubber	Good resistance to mild acids, detergents, alkalis, ketones, and alcohols.	-40°F (-40°C)	250°F (121°C)
FKM	Fluorocarbon Rubber	Good chemical resistance and high temperature properties. Resistant to most acids, aliphatic, aromatic, and halogenated hydrocarbons, oils, grease, and fuels.	-40°F (-40°C)	350°F (177°C)
Neoprene	Chloroprene Rubber	General purpose elastomer with good resistance to moderate chemicals, oils, grease, solvents, and some refrigerants.	0°F (-18°C)	212°F (100°C)
Santoprene™	Fully cured EPDM rubber particles encapsulated in a polypropylene (PP) matrix	Thermoplastic elastomer with good abrasion resistance with chemical resistance to a wide range of solvents and chemicals. Injection molded with no fabric layer.	-40°F (-40°C)	225°F (107°C)
Hytrel®	Thermoplastic polyester elastomer	Combines resistance and flexibility of elastomers with the strength of plastics. Resistant to acids, bases, amines, and glycols. Injection molded with no fabric layer.	-20°F (-29°C)	220°F (104°C)
Polyurethane	Polyester Urethane	Thermoplastic that exhibits excellent abrasion resistance. Injection molded with no fabric layer.	32°F (0°C)	150°F (66°C)
PTFE	Polytetrafluoroethylene	Chemically inert. Resistant to a wide range of chemicals.	40°F (4°C)	225°F (107°C)
FEP	Fluorinated Ethylene Propylene	Similar to PTFE in composition and chemical resistance. Used to encapsulate FKM o-rings for superior chemical resistance.	40°F (4°C)	225°F (107°C)

Santoprene™ is a registered tradename of Exxon Mobil Corp.

Hytrel® is a registered tradename of Dupont™

FT30S Dimensional Drawing



Model Number Explanation & Example Part Numbers

PART #	XX	XX	X	-	X	-	X	X	X	-	X	X	-	X
	Series	Pump Size	Wetted Material		Non-wetted Material	Air Valve Material	Diaphragm Material	Check Valve Ball	Check Valve Seat		Seat O-ring	Connection	Porting Location	Specials

Series*

FT - Pump End
FW - Wet End

Pump Size*

30 - 3"

Wetted Materials*

A - Aluminum
S - 316SS, FDA

Non-wetted Materials

A - Aluminum**

Air Valve Materials

P - GFRPP **A** - Aluminum**

Diaphragm Materials*

N - Neoprene **1** - PTFE/Neoprene
B - Buna-N, FDA **2** - PTFE/Santoprene
E - EPDM **3** - PTFE/Buna-N, FDA
F - FKM **4** - PTFE/Santoprene, FDA
R - Santoprene **5** - Santoprene, FDA
U - Polyurethane **6** - Hytrel, FDA
H - Hytrel

Check Valve Ball Materials*

N - Neoprene **F** - FKM
B - Buna-N **T** - PTFE, FDA
E - EPDM **W** - Weighted PTFE, FDA
S - 316SS, FDA **5** - Santoprene, FDA
R - Santoprene

Check Valve Seat Materials*

A - Aluminum **S** - 316SS, FDA
T - PTFE, FDA **B** - Buna-N
F - FKM **E** - EPDM
R - Santoprene **H** - Hytrel
N - Neoprene **U** - Polyurethane

Check Valve Seat O-Ring Materials*

N - Neoprene **F** - FKM
B - Buna-N **E** - EPDM
C - FEP/FKM, FDA **0** - None
T - PTFE, FDA

Connection

N - FNPT **B** - FBSP
F - ANSI/DIN/ISO Flange **T** - Tri-Clamp

Porting location

2 - Center horizontal

Specials

A - ATEX **M1** - Metal muffler
P1 - Halogenated hydro-carbon compatible **M2** - Oversized metal muffler


*Required for wet end

**Required for ATEX


Example Pump P/N's: FT30A-AA-NNAN-N2, FT30A-PP-BBAB-B2, FT30S-AA-1TST-F2, FT30S-PP-EESE-B2

Example Wet End P/N's: FW30A-NNAN, FW30A-BBAB, FW30S-1TST, FW30S-EESE


FT30A Dimensional Drawing



FT30S & FT30A Performance Curve



Installation Drawing



PUMP MUFFLER IS ON THE BACK SIDE OF THE PUMP.
IT CAN BE REMOVED AND EXHAUST CAN BE PIPED TO DESIRED LOCATION.

Installation / Operation Precautions

Installation and Start up

Install the pump in a vertical position or it may not prime properly. Pump should be located as close to the product being pumped as possible. Suction line length should be as short as possible and limit the number of fittings. Suction line diameter should not be reduced smaller than the suction diameter of the pump. When using rigid pipe run short sections of flexible hose or flexible connections between the pump & piping. Secure the pump to a suitable surface.

Air Supply

Connect the pump air inlet to an air supply with sufficient capacity to achieve desired performance. A pressure regulating valve should be installed to ensure air supply pressure does not exceed recommended limits.

Air Valve Lubrication

No lubrication is required for the air distribution system.

Fasteners

Re-torque all fasteners before operation. Creep of housing and gasket materials may cause fasteners to loosen. Re-torque all fasteners to the torque specifications listed on the exploded view drawing in this manual.

Air Inlet & Priming

Pump will start to operate as soon as the shut-off valve is opened. It is recommended to open the shut-off valve slowly at first. Once the pump primes; the shut-off valve can be opened additionally to increase the pump's flow. If the pump is operating but not pumping any liquid see the troubleshooting section for tips & suggestions.

Accessories

Surge suppressors, spill stops & filter regulators are available and should be used with FTI Air pumps.

Troubleshooting Tips & Suggestions

PUMP WILL NOT START OR CYCLE:

- Blocked liquid pipe or hose - Clean out or replace
- Clogged liquid chamber - Remove debris
- Diaphragm shaft bushing / o-ring leak - Replace o-rings
- Air valve carrier not shifting - Inspect, clean, re-oil with 10 wt. air tool oil. (aluminum air valve)
- Air valve carrier not shifting - Inspect, replace seals (polypropylene air valve)

ERRATIC CYCLING:

- Diaphragm failure - Replace diaphragm
- Valve ball not seating properly, worn or damaged – Inspect, remove debris or replace
- Leak in suction line - Inspect, repair or replace
- Diaphragm shaft bushing / o-ring leak - Replace o-rings
- Air valve carrier not shifting - Inspect, clean, re-oil with 10 wt. air tool oil. (aluminum air valve)
- Air valve carrier not shifting - Inspect, replace seals (polypropylene air valve)
- Over lubrication in air valve - Inspect, degrease, reuse. Adjust lubrication
- Excess moisture in air valve – Inspect, dry, reuse. Consider installing an air dryer
- For aluminum air valves, worn carrier or valve bore – measure carrier and valve bore, diametrical clearance should be between .0020” - .0035”. Replace worn components as needed
- For plastic air valves, worn carrier seals – replace carrier seals if there is no longer interference between seals and valve bore

PUMP CYCLES BUT WILL NOT PUMP:

- Too much suction lift - Reduce suction lift or fill liquid chambers with liquid
- Leak in suction line - Inspect, repair or replace
- Valve ball not seating properly, worn or damaged - Inspect, remove debris or replace
- Clogged suction pipe or hose - Inspect & clear
- Clogged strainer if used - Inspect & clear
- Diaphragm failure - Replace diaphragm

PUMPED LIQUID RELEASED FROM AIR EXHAUST

- Diaphragm failure - Replace diaphragm
- Outer plate unthreading - Tighten & re-torque

Maintenance

Recommended Tools for Servicing Pump


- 13 mm, 16 mm, & 18 mm box wrenches; (2) 32 mm socket wrenches, snap ring pliers; 5 & 6 mm hex wrenches, o-ring pick, & torque wrench.

Wet End Servicing (Installing Wet End Kit)

- Relieve airline pressure and fluid line pressures before conducting maintenance.
- The pump can be drained by turning it upside down and allowing fluid to drain into an appropriate container. Use proper safety equipment when conducting maintenance as internal components may still contain the pumped media.
- Lubricate all stainless steel to stainless steel fasteners to prevent galling. Torque values listed in the back of this manual are for lubricated fasteners.

Wet End Disassembly

- ❶ Remove the (8) discharge manifold bolts (item 11) from the discharge manifold (item 40) using a 16 mm wrench.




- ❷ The discharge seat o-rings, valve seats and valve balls (items 13, 14, & 15) can now be accessed and replaced if needed.



- ❸ Repeat the above steps for the suction manifold (item 12). The seat o-rings, valve seats and valve balls (items 13, 14, & 15) are located in the liquid chambers (item 19).




- ❹ Remove both liquid chambers (item 19) by removing the (10) bolts & nuts (item 16, 18, & 28) on each liquid chamber using a 16 mm wrench. Inspect and replace diaphragms if needed.



- ❺ To remove the diaphragms (items 21/22), begin by loosening the (2) outer plates (item 20) using two 32 mm wrenches.



6 Remove the outer plate, diaphragm(s), and inner plate (items 20, 21/22 & 23) from the side that is loosened. Pull or push the shaft (item 33) and remaining plates and diaphragms out of the center section. If pulling, it may be easier to grip the diaphragm if it is inverted.



7 To remove the remaining diaphragm(s) (items 21/22) and plates (items 20 & 23) from the shaft (item 33), place the shaft in a vise. Using a 6-sided 32 mm wrench, remove the remaining diaphragm(s) and plates.



8 To remove diaphragms from inner & outer plates, remove the (6) bolts and washers (items 24, 25, & 26) that connect the inner plates to the outer plates using a 13 mm wrench.



After performing required maintenance, the pump can be reassembled. The pump can also be reassembled using the disassembly instructions in the reverse order as listed above. For detailed assembly instructions, follow steps in Wet End Reassembly section beginning on page 15.

Wet End Reassembly

- 1 Place the diaphragm (item 22) on the outer plate (item 20).


If the pump is fitted with PTFE diaphragms (item 21), first place a PTFE diaphragm on the outer plate (item 20). Then place the backup diaphragm (item 22) on the PTFE diaphragm. The shape of the PTFE diaphragm and back up diaphragm should roughly conform to one another. See the exploded view drawing for proper orientation.



- 2 Place the inner plate (item 23) on the diaphragm. Ensure the round recess in the plate faces the diaphragm (item 22). Tighten the (6) bolts (items 24, 25, & 26) in a star pattern using a 13 mm wrench.




- 3 Place the bump stop (item 32) onto one end of the shaft (item 33).



- 4 Apply a couple drops of a medium strength thread locker, such as Loctite® 246, to the threads on end of shaft. Thread the shaft (item 33) into the outer plate (item 20) until it is snug.




5 The shaft (item 33) and shaft o-rings (item 31) should retain the lubricant that was factory applied. If they appear dry, apply a light coat of lithium thickened grease. Avoid over-lubrication as it can cause decreased performance of the air distribution system.



6 Push the shaft (item 33) through the center of the shaft bushing (item 30). It is normal for this to be a tight fit, especially if the shaft and shaft o-rings (item 31) are in good condition.



7 Place the remaining bump stop (item 32) on the other end of the shaft (item 33).



8 It may be easier to thread the outer plate (item 20) onto the shaft (item 33) if the diaphragm(s) is inverted on one or both sides. This can be done by hand.



9 The other diaphragm(s) (items 21/22) and inner/outer plates (items 20 & 23) can be installed onto the opposite end of the shaft (item 30).



10 Tighten and torque the outer plates (item 20).



11 Install the liquid chambers (item 19) by placing one side over the diaphragm. Start all bolts & nuts (items 16, 18, 28) before tightening and torquing. Torque all fasteners in a star pattern. Repeat to install the second liquid chamber. Ensure both chambers are orientated the same and that the inlet and outlet ports are vertical when facing the front of the pump as shown.




12 Flip the pump upside down and drop the suction valve balls (item 15) into the liquid chamber (item 19) ball cages.



13 For pumps fitted with metal or PTFE valve seats (item 14), place the valve seat o-rings (item 13) into the glands on both sides of the valve seat. Pumps fitted with rubber or TPE seats do not require valve seat o-rings. All seats are symmetrical, i.e. there is no top or bottom.



14 Place the valve seats (item 14) into the seat bore in the liquid chamber (item 19). Place the suction manifold (item 12) atop the pump, install, tighten and torque the (8) manifold bolts (item 11).



15 Stand the pump upright onto the suction manifold feet. Place the valve seat o-rings (item 13) into both sides of the valve seat. Place the seat on the liquid chamber (item 19). Place the valve balls (item 15) on the seats and discharge manifold (item 40) atop the components that are stacked on top of the liquid chambers. Install, tighten and torque the (8) manifold bolts (item 11).



Air End Servicing (Installing Air End Kit)


- Follow steps 1 – 7 in the Wet End Servicing disassembly section to access the shaft bushing (item 30) and o-rings (items 29 & 31), then follow steps below.

Shaft, Bushing, & O-ring Replacement

- 1 Remove both air chambers by removing the (4) bolts & washers (items 24 & 26) on each side of the pump with a 13mm wrench.



- 2 Remove and set aside the air valve (item 3) using a 6mm hex wrench (see Valve and Muffler Gasket Replacement section for more details). The shaft bushings can be removed by placing a large socket between the two bushings. Place an extension into the socket from one side of the center section (item 36). Tap with a rubber mallet to remove the bushing. Repeat for the remaining bushing.



- 3 Use the supplied grease packets to lightly grease the OD and ID o-rings (items 29 & 31) that come preinstalled in the new shaft bushings supplied in air end kits.



- 4 Insert both bushings into the center section. Ensure the bushing is fully installed and the large rib on the outside of the bushing is flat against the center section.




5 Inspect the shaft (item 33) for damage. It is common for shafts to become grooved during service. Grooving is normally caused by carbonized oil and/or abrasive foreign material getting trapped between the seal and the shaft. Over time, deep grooves can form in the shaft. When that occurs, it is recommended that the shaft be replaced.



6 After determining if the condition of the shaft is acceptable, ensure both center section o-rings (items 34 & 35) are in place on both sides of the center section.



7 Install air chambers (item 27) by placing one side on top of the center section (item 36). Ensure the air path hole of the center section lines up with the through hole in the air chamber.




8 Tighten and torque the (4) fasteners (items 24 & 26) that connect the air chamber (item 27) to the center section (item 36). Repeat for the second air chamber.




• To rebuild the rest of the pump, follow steps 5 – 15 in the Wet End Servicing – Wet End Reassembly section.

Air Valve O-Ring Replacement


1 Plastic Air Valve - To replace the valve cap o-rings remove the retaining ring (item 8), then pull the valve cap (item 6) straight up. The use of an M8 bolt, vise grip, and pry bars may be necessary. See 1 and 1A pictures below.




2 Plastic Air Valve - Remove and replace o-rings (item 5). Insert cap (item 6) and push down until groove for the retaining ring is visible. Install retaining ring. Make sure to lubricate the o-rings prior to inserting into the valve body with a compatible lubricant.



1 Aluminum Air Valve - To replace the valve cap o-rings (item 5), remove the (3) button head cap screws (item 7) using a 5 mm hex wrench.



2 Aluminum Air Valve - Remove and replace o-ring (item 5). Install cap (item 6), tighten, and torque the valve cap screws (item 7). Repeat for the remaining cap.



Valve and Muffler Gasket Replacement

1 Remove the valve body (item 3) by removing the (4) socket head cap screws and washers (items 1 & 2) that attach the valve body to the muffler plate (item 38) with a 6 mm hex wrench






2 Pull the valve body and gasket (items 3 & 37) off the front of the center section (item 36) and the muffler plate gasket, muffler plate and muffler (items 38, 39, & 41) off the back.



3 Place the new gasket (item 37) on the air valve (item 3) and ensure the slots in the gasket align with the slots in the air valve and valve plate (item 10).

Air Valve Slide, Plate & Gasket Orientation: If the valve plate (item 10) and slide valve (item 9) are removed, ensure they are installed in the proper orientation. The flat face of the slide valve sits in the pocket of the valve carrier (item 4) so that the square cut out on the slide valve faces the smooth polished side of the valve plate




4 Insert the (4) cap screws & washers (items 1 & 2) through the valve body and gasket (items 3 & 37) and place onto the center section (item 36). Ensure the slide valve and valve plate (items 9 & 10) are in place and the valve sits flat on the center section.



5 Place the muffler gasket (item 38) over the (4) cap screws (item 1) on the back side of the center section (item 36) followed by the muffler plate and muffler (items 39 & 41).




6 Tighten and torque the (4) cap screws & washers (items 1 & 2) into the muffler plate.



Replacement Air Valve Kit Installation

1. Remove the valve that is to be replaced by removing the (4) socket head cap screws with a 6 mm hex wrench that attaches the valve body to the muffler plate.
 2. Save the (4) cap screws, (4) lock washers, muffler plate, and muffler. All other valve components can be discarded.
 3. Remove the packing tape that holds the air valve components in place during shipping.
- Follow steps 3 – 6 in the Valve and Muffler Gaskets section of Air End Servicing above.

Exploded View & Spare Parts List



ITEM	DESCRIPTION	PART NO.	QTY	KIT
3	VALVE BODY	SEE AIR VALVE TABLES		V1/V2
4	VALVE CARRIER	SEE AIR VALVE TABLES		V1/V2
5	VALVE CAP O-RING	SEE AIR VALVE TABLES		V1/V2
6	VALVE CAP	SEE AIR VALVE TABLES		V1/V2
9	SLIDE VALVE	109697	1	V1/V2
10	VALVE PLATE	109628	1	V1/V2
12	MANIFOLD, SUCTION, ALUMINUM	SEE MANIFOLD TABLES		
	MANIFOLD, SUCTION, STAINLESS STEEL, FDA			

ITEM	DESCRIPTION	PART NO.	QTY	KIT
13	O-RING, VALVE SEAT, NEOPRENE	109314	8	W
	O-RING, VALVE SEAT, BUNA-N	109309		
	O-RING, VALVE SEAT, EPDM	J103003		
	O-RING, VALVE SEAT, FKM	J102960		
	O-RING, VALVE SEAT, PTFE, FDA	109319		
	O-RING, VALVE SEAT, FEP ENCAPSULATED FKM, FDA	109599		
14	VALVE SEAT, ALUMINUM - REQUIRES ITEM 13	109239	4	W
	VALVE SEAT, STAINLESS STEEL, FDA - REQUIRES ITEM 13	109243		
	VALVE SEAT, PTFE, FDA - REQUIRES ITEM 13	109598		
	VALVE SEAT, NEOPRENE (GREEN DOT)	109231		
	VALVE SEAT, BUNA-N (RED DOT)	109235		
	VALVE SEAT, EPDM (BLUE DOT)	109443		
	VALVE SEAT, FKM (WHITE OR SILVER DOT)	109289		
	VALVE SEAT, SANTOPRENE (RED)	109247		
	VALVE SEAT, SANTOPRENE, FDA (NATURAL)	109247-1		
	VALVE SEAT, HYTREL (CREAM)	109227		
	VALVE SEAT, HYTREL, FDA (NATURAL)	109227-1		
	VALVE SEAT, POLYURETHANE (BEIGE)	109304		
15	VALVE BALL, NEOPRENE (GREEN DOT)	109206	4	W
	VALVE BALL, BUNA-N (RED DOT)	109210		
	VALVE BALL, EPDM (BLUE DOT)	109214		
	VALVE BALL, FKM (WHITE OR SILVER DOT)	109218		
	VALVE BALL, SANTOPRENE (RED)	109222		
	VALVE BALL, SANTOPRENE, FDA (NATURAL)	109222-1		
	VALVE BALL, PTFE, FDA (WHITE)	109202		
	VALVE BALL, 316 STAINLESS STEEL, FDA	109371		
	VALVE BALL, WEIGHTED PTFE, FDA (WHITE BALL)	109380		
19	LIQUID CHAMBER, ALUMINUM	109767-15	2	
	LIQUID CHAMBER, STAINLESS STEEL	109767-16		
20	OUTER PLATE, ALUMINUM	109162	2	
	OUTER PLATE, STAINLESS STEEL	109166		
21	DIAPHRAGM, PTFE, FDA (WHITE) - REQUIRES BACK UP	109185-1	2	W
22	DIAPHRAGM, NEOPRENE (GREEN DOT)	109189-1	2	W
	DIAPHRAGM, BUNA-N, FDA (RED DOT)	109189-2		
	DIAPHRAGM, EPDM (BLUE DOT)	109189-3		
	DIAPHRAGM, FKM (WHITE OR SILVER DOT)	109189-4		
	DIAPHRAGM, SANTOPRENE (RED)	109197		
	DIAPHRAGM, SANTOPRENE, FDA (NATURAL)	109197-1		
	DIAPHRAGM, HYTREL (CREAM)	109193		
	DIAPHRAGM, HYTREL, FDA (NATURAL)	109193-1		
	DIAPHRAGM, POLYURETHANE (BEIGE)	109438		
23	INNER PLATE	109171	2	
27	AIR CHAMBER, ALUIMINUM	109147	2	
29	O-RING, BUSHING OD	109420	4	A1/A2
30	SHAFT BUSHING W/ O-RINGS (ITEMS 29 & 31)	109710	2	A1/A2
31	O-RING, BUSHING ID	109424	6	A1/A2

ITEM	DESCRIPTION	PART NO.	QTY	KIT
32	BUMP STOP	109430	2	
33	SHAFT	109176	1	
34	O-RING, CENTER SECTION, LARGE	109434	2	A1/A2
35	O-RING, CENTER SECTION, SMALL	109418	2	A1/A2
36	CENTER SECTION, ALUMINUM	109460-1	1	-
37	GASKET, AIR VALVE	109267	1	V1/V2
38	GASKET, MUFFLER	109428	1	V1/V2
39	MUFFLER PLATE	109271	1	-
	MUFFLER PLATE ATEX	109271-1	1	-
40	MANIFOLD, DISCHARGE, ALUMIUM	SEE MANIFOLD TABLES		-
	MANIFOLD, DISCHARGE, STAINLESS STEEL			-
41	MUFFLER	109562	1	-
	MUFFLER ATEX	109700	1	-
42	GROUNDING LUG	108091	1	-
43	SPLIT FLANGE HALF	SEE MANIFOLD TABLES		-
45	SHIM - POLYETHYLENE	109765	4	-

FT30A & FT30S Kits		
Kit Key	Description	Part No.
W	PARTS SUPPLIED IN WET END KITS	-
A1	PARTS SUPPLIED IN PLASTIC VALVE AIR END KIT	109708
A2	PARTS SUPPLIED IN ALUMINUM VALVE AIR END KIT	109706
V1	PARTS SUPPLIED IN PLASTIC REPLACEMENT VALVE KIT	111251
V2	PARTS SUPPLIED IN AN ALUMINUM REPLACEMENT VALVE KIT	109707

PUMPS FITTED WITH GFRPP AIR VALVES FT30_-P-____-__				
ITEM	DESCRIPTION	PART NO.	QTY	KIT
3	VALVE BODY, GFRPP	109904	1	V1
4	VALVE CARRIER WITH SEALS	111366	1	V1
5	VALVE CAP O-RING	109580	4	V1
6	VALVE CAP, DELRIN	109892	2	V1
8	RETAINING RING, HO-165 SS	109645	2	V1

PUMPS FITTED WITH ALUMINUM AIR VALVES FT30_-A-____-__				
ITEM	DESCRIPTION	PART NO.	QTY	KIT
3	VALVE BODY, ALUMINUM	SEE ITEM 44	1	V2
4	VALVE CARRIER, ALUMINUM	109456	1	V2
5	VALVE CAP O-RING	109416	2	V2
6	VALVE CAP, ALUMINUM	SEE ITEM 44	2	V2
7	CAP SCREW, SOC. HD M6X1.0X16	109513	6	V2
44	CONTAINS ITEMS 3, ,4, 5, 6, & 7	109593	1	V2

SUCTION MANIFOLD (ITEM 12)								
	LAST 2 DIGITS OF MODEL NUMBER							
BEGINNING OF MODEL NUMBER	N2		B2		F2		T2	
	PART NO.	QTY	PART NO.	QTY	PART NO.	QTY	PART NO.	QTY
FT30A - ITEM 12	109126	1	109126-1	1	N/A	-	N/A	-
FT30S - ITEM 12	109130	1	109130-1	1	109130	1	109130-10	1
ITEM 43 (NOT SHOWN)	N/A	-	N/A	-	109634	2	N/A	-
DISCHARGE MANIFOLD (ITEM 40)								
	LAST 2 DIGITS OF MODEL NUMBER							
BEGINNING OF MODEL NUMBER	N2		B2		F2		T2	
	PART NO.	QTY	PART NO.	QTY	PART NO.	QTY	PART NO.	QTY
FT30A - ITEM 40	109141	1	109141-1	1	N/A	-	N/A	-
FT30S - ITEM 40	109145	1	109145-1	1	109145	1	109145-10	1
ITEM 43 (NOT SHOWN)	N/A	-	N/A	-	109634	2	N/A	-

FT30A & FT30S Maximum Torque Settings*			
Stainless Steel Pumps		Aluminum Pumps	
Item #	Torque	Item #	Torque
1	8.5 N-m (75 in-lbs)+	1	10N-m (90 in-lbs)
7	8 N-m (72 in-lbs)	7	8 N-m (72 in-lbs)
11	63 N-m (552 in-lbs)+	11	75 N-m (660 in-lbs)
16	63 N-m (552 in-lbs)+	16	75 N-m (660 in-lbs)
17	63 N-m (552 in-lbs)+	17	75 N-m (660 in-lbs)
20	108 N-m (960 in-lbs)+	20	108 N-m (960 in-lbs)+
26	24 N-m (216 in-lbs)	26	24 N-m (216 in-lbs)
Asterisk (*) from the exploded view diagram indicates fasteners to be torqued. Stainless steel to stainless steel fasteners should be lubricated to prevent galling. A Plus sign (+) on the above torque values indicates a lubricated fastener.			

MODEL FT30A HARDWARE

ITEM	DESCRIPTION	PART NO.	QTY
1	CAP SCREW, SOCKET HD M8X1.25X120MM	109495	4
2	WASHER, LOCK M8 HIGH-COLLAR	109493	4
11	CAP SCREW, HEX HD FLNG M12X1.75X35MM	109480	16
16	CAP SCREW, HEX HD FLNG M12X1.75X60MM	109481	12
17	CAP SCREW, HEX HD M12X1.75X140MM	109491	8
18	WASHER, FLAT M12	109490	8
24	WASHER, FLAT M8	109469	20
25	WASHER, LOCK M8	109475	12
26	CAP SCREW, HEX HD M8X1.25X30MM	109471	20
28	NUT, HEX HD FLNG M12X1.75	109486	20

MODEL FT30S HARDWARE

ITEM	DESCRIPTION	PART NO.	QTY
1	CAP SCREW, SOCKET HD M8X1.25 X 120MM SS	109520	4
2	WASHER, LOCK M8 HIGH-COLLAR SS	109518	4
11	CAP SCREW, HEX HD FLNG M12X1.75 X 35MM SS	109501	16
16	CAP SCREW, HEX HD FLNG M12X1.75 X 50MM SS	109502	12
17	CAP SCREW, HEX HD M12X1.75X80MM SS	109503	8
24	WASHER, FLAT M8	109469	20
25	WASHER, LOCK M8	109475	12
26	CAP SCREW, HEX HD M8X1.25X30MM	109471	20
28	NUT, HEX HD FLNG M12X1.75 SS	109510	20
46	WASHER, FLAT 1/2" SS	J103851	8
47	CAP SCREW, HEX HD 1/2"S13"X2" SS	J104032	4
48	NUT, HEX 1/2"X13 SS	107534	4

Warranty



FTI Air A Division of Finish Thompson, Inc (manufacturer) warrants this pump product to be free of defects in materials and workmanship for a period of **five years** from date of purchase by original purchaser. If a warranted defect, which is determined by manufacturer's inspection, occurs within this period, it will be repaired or replaced at the manufacturer's option, provided (1) the product is submitted with proof of purchase date and (2) transportation charges are prepaid to the manufacturer.

Liability under this warranty is expressly limited to repairing or replacing the product or parts thereof and is in lieu of any other warranties, either expressed or implied. This warranty does not apply to normal wear of the product or components. This warranty does not apply to products or parts broken due to, in whole or in part, accident, overload, abuse, chemical attack, tampering, or alteration. The warranty does not apply to any other equipment used or purchased in combination with this product. The manufacturer accepts no responsibility for product damage or personal injuries sustained when the product is modified in any way. If this warranty does not apply, the purchaser shall bear all cost for labor, material and transportation.

Manufacturer shall not be liable for incidental or consequential damages including, but not limited to process down time, transportation costs, costs associated with replacement or substitution products, labor costs, product installation or removal costs, or loss of profit. In any and all events, manufacturer's liability shall not exceed the purchase price of the product and/or accessories



FINISH THOMPSON INC. - HEADQUARTERS

921 Greengarden Road | Erie, PA 16501
800.934.9384 | ph 814.455.4478 | fx 814.455.8518
email fti@finishthompson.com

FINISH THOMPSON GMBH - EUROPE CENTER

Otto-Hahn-Strasse 16 | Maintal, D-63477 Germany
49 (0)6181-90878-0 | fx 49 (0)6181-90878-18
email europescenter@finishthompson.com